



NOTES:

- THE AMPS ARE DETERMINED BY THE MAXIMUM AMP READING DESIRED.  
ex. 0-50 AMP SHUNT = 0 TO 50 AMPS ON DIGITAL METER.  
ex. 0-100 AMP SHUNT = 0 TO 100 AMPS ON DIGITAL METER.

File: DC\_AAM.dwg